

Function	German Keyboard	U.S. Keyboard
Left MCDU Kybd ON/OFF	Strg+Umschalt+1	Ctrl+Shift+1
Right MCDU Kybd ON/OFF	Strg+Umschalt+2	Ctrl+Shift+2
LSK 1L	F1	F1
LSK 2L	F2	F2
LSK 3L	F3	F3
LSK 4L	F4	F4
LSK 5L	F5	F5
LSK 6L	F6	F6
LSK 1R	F7	F7
LSK 2R	F8	F8
LSK 3R	F9	F9
LSK 4R	F10	F10
LSK 5R	F11	F11
LSK 6R	F12	F12
MSG	Strg+F1	Ctrl+F1
Dir/Intc	Strg+F2	Ctrl+F2
Fpln	Strg+F3	Ctrl+F3
Dep/Arr	Strg+F4	Ctrl+F4
Hold	Strg+F5	Ctrl+F5
MCDU Menu	Strg+F6	Ctrl+F6
Index	Strg+F7	Ctrl+F7
Fix	Strg+F8	Ctrl+F8
Legs	Strg+F9	Ctrl+F9
Sec Fpln	Strg+F10	Ctrl+F10
VNAV	Strg+F11	Ctrl+F11
Exec	Return oder Strg+F12	Return or Ctrl+F12
Radio	Umschalt+F1	Shift+F1
Prog	Umschalt+F2	Shift+F2
Perf	Umschalt+F3	Shift+F3
MFD Data	Umschalt+F4	Shift+F4
MFD Menu	Umschalt+F5	Shift+F5
MFD Adv	Umschalt+F6	Shift+F6
A-Z	A-Z	A-Z
0-9	0-9	0-9
.	.	.
+	+	+
-	-	-
/	/	/
SP	Leertaste	Space
DEL	Entf	Delete
CLR	Zurück	Backspace